

## DATA SHEET



### POP I Polishing Pad One

Explanation:	The very close fibre formation, combined with the softness of the nap, ensures that the pad holds the polish evenly over the pad surface for maximum polishing. This pad has precision rayon flock fibers coated onto a poly/cotton fabric backing of a uniform thickness and flatness which conforms accurately to any tool curve, giving a more perfect curve reproduction than what is normally achievable. The specially developed adhesive used to adhere the flock to the base material reduces flock loss in the polish to a minimum.
Product Description:	Uniform, dense flock pile for high slurry absorption and smooth polishing. High shear resistance and clear removable adhesive
Directions for use:	This pad is suitable for plastic lenses
Physical Properties:	Adhesive: Excellent removable acrylic adhesive providing good creep resistance and clean removability.
Carrier:	Poly / Cotton Fabric
Face side:	White rayon flock fibers
Abrasion:	Wet Taber Abrasion Resistance (CS/500g):500 cycles
Total Thickness:	0,71 - 0,83 mm
Liner:	White Glassine Paper
Temperature :	+55°C
Shelf Life:	Two years from despatch when stored in original bags and cartons at 21°C and under 30-70% relative humidity

*Data and details in this sheet were correct and up-to-date at the time of printing and are intended to provide information on our products and their possible applications. This sheet is not a specification and does not assure specific product characteristics or make reference to the suitability of the products for a definite application. Because Permanento cannot anticipate or control every application, we strongly recommend testing of this product under individual application conditions. In accordance with our policy of continuous improvement specification may vary.*

Permanento Edge-it B.V.  
Bliet 10  
Industrial Estate Dombosch 1  
4941 SG Raamsdonksveer  
The Netherlands  
Tel: +31 162 58 94 00  
Fax: +31 162 52 02 14  
[r.hertzberger@permanento.com](mailto:r.hertzberger@permanento.com)  
[w.kraaij@permanento.com](mailto:w.kraaij@permanento.com)

