
DATA SHEET



NOSE PAD HEADER CARD

Product Description: This Nose pad is made out of a highly resilient flexible clear non yellowing polyurethane with a high tack acrylic adhesive. This product is Uv plus ageing resistant and the adhesive also adheres on difficult to bond surfaces. This long lasting nose pad is available in a sheets of 10 pieces in size 13mm, 15mm and 17mm

Directions for use: It is important that you clean the frame Nose Pad surface with alcohol and wait till the alcohol is evaporated. Avoid products like benzene and turpentine. You will have 50% adhesion in 10 minutes and 100% in 72hrs.

Physical Properties:

Adhesive: Acrylic

Carrier: Highly resilient flexible polyurethane

Total Thickness: 0,8 mm

Liner: Transparent PET

Temperature : +80°C

Shelf Life: 12 months from despatch when stored in original bags and cartons at 21°C and under 50% relative humidity

Data and details in this sheet were correct and up-to-date at the time of printing and are intended to provide information on our products and their possible applications. This sheet is not a specification and does not assure specific product characteristics or make reference to the suitability of the products for a definite application. Because Permanento cannot anticipate or control every application, we strongly recommend testing of this product under individual application conditions. In accordance with our policy of continuous improvement specification may vary.