

## W84I DIGITAL FRAME WARMER

(HIGH CLASS)

### MECHANISM AND ACCESSORIES

**Digital temperature:** Display the real-time work temperature inside the housing.

**Temperature control system:** The standard version of frame heater is fitted with an electronic system to monitor and control the actual work temperature inside. It records the latest work temperature when restart the machine.

**Heat collecting device:** The heated air is collected through one wind outlet for special frame or position of frame.

### SPECIFICATIONS

Power supply.....	AC 100~120V/60Hz,200~240V/50Hz
Motor.....	6W
Available temperature.....	40°C~140°C
Power of Heating wires.....	580W
Power rating.....	800W
Wind speed.....	1.8m/s
Weight.....	1.26kgs
Dimension.....	235mmX125mmX250mm

### OPERATION GUIDE

1. Turn on power switch
2. Turn on heating switch
3. Adjust the temperature you need by the temperature adjustment key ⊕ ⊖



**RJ-84** Round Jet

**PB-84** Plastic Baker

